

# Instructional Manual Continuous Ink System for use with Brother MFC-290C/235/260C/6490C/490CW

Before using this product, please read and follow all instructions. After opening your package, make sure to check that all the accessories are included.

## 1. Accessories

a. Continuous Ink System (1)



b. Air breathers (4)



## 2. Set-Up Continuous Ink System (CIS)

a. Before installation, lay out all your parts in front of your printer.

b. Check your system for any leaking and no visible defects.

c. Remove the small plug from the cartridge (Fig.2-1) and install the air breathers wide end side into the cartridge (Fig.2-2).



Fig.2-1



Fig.2-2

## 3. Cartridge Installation

a. When installing the cartridges, it is important that you insert them from left to right with the black cartridge first (Fig.3-1) and the magenta cartridge last. The reason for this is because the magenta cartridge has a clip on top of it that goes into the cartridge door sensor (Fig.3-2). The clip needs to push the sensor in so the printer is able to function with the cartridge door open. If you insert the magenta cartridge first, the printer will think the cartridge door is closed and you will get a error message for the other missing cartridges.

b. Once all cartridges are inserted as shown (Fig.3-3), installation is complete. Turn on printer and make sure the system runs smoothly.



Fig. 3-1



Fig.3-2



Fig.3-3

#### 4. Refilling Ink

To refill the cartridges, follow these steps:

1. Take out the cartridge from the printer and remove the big plug from the cartridge (Fig.4-1).
2. Refill the proper color of ink into the corresponding cartridge (Fig.4-2) and use a damp paper towel to wipe off any ink that has spilled.
3. Make sure you use the low foam inks for the System as they are specifically designed for optimal results.



Fig.4-1



Fig.4-2

#### 5. Attention:

1. From time to time please remove the air breathers and rinse them thoroughly with water to remove any ink that has built up and let them dry prior to reinstalling them.
2. Store between 15-35 degrees Celsius.

#### 6. Caution:

1. Do not ingest ink and keep out of reach of children.
2. Do not leave under sunlight or in extreme weather conditions.

Troubleshooting tips		
	Problem	Suggestion
1	Banding or white lines in my print outs.	There is air in the system or cartridges, try running a couple of cleaning cycles.
2	After you installed the C.I.System, it can't print or cartridges are not recognizing.	Cartridge may not be installed correctly. You need to remove and reinstall cartridges again.
3	If you are still unable to fix the problem call your dealer for support.	